

TECHNICAL DATA

Fluke BTL-A Voltage/Current Probe Adapter



Product overview: Fluke BTL-A Voltage/Current Probe Adapter

Voltage/current probe adapter for Fluke 500 Series Battery Analyzers. The BTL-A allows connection of standard 4mm banana plug test leads or current clamp adapter. Allows the BT521 Series Battery Analyzer to make AC and DC voltage and current measurements using the Fluke i410 AC/DC Current Clamp.

Ordering information



Fluke BTL-A

Voltage/Current Probe Adapter

Fluke. *Keeping your world up and running.®*

Fluke Corporation

PO Box 9090, Everett, WA 98206 U.S.A.

For more information call:

In the U.S.A. (800) 443-5853

In Europe/M-East/Africa +31 (0)40 267 5100

In Canada (800)-36-FLUKE

From other countries +1 (425) 446-5500

Fluke Electronics (Malaysia) Sdn Bhd

Suite D-3A-4, Block D

SouthGage Commercial Centre, No2

Jalan Dua Off Jln Chan Sow Lin

55200 KL

Malaysia

Email: info.asean@fluke.com

www.fluke.com/my

©2025 Fluke Corporation. Specifications subject to change without notice.

04/2025

Modification of this document is not permitted without written permission from Fluke Corporation.